

Eddy's Boilerhouse News

TIP OF THE MONTH FOR THE MAINTENANCE DEPARTMENT

By Eddy Emerson

In all the training classes no one has ever asked for a list of Flame Signal Reading until this year. And, I thought it was such a good idea that I decided to post them on my news letter. So here they are:

Flame Signal Reading

FIREYE CONTROLS

| | |
|---|--------------------------------------|
| UVM Series | 4.0 – 5.5 VDC |
| TFM Series | 14 – 17 VDC |
| D – 10/20/30 Series | 16 – 25 VDC |
| E-100 / E110 Series | 10 Minimum 20 – 80 Normal |
| E100 / E110 Series w/ EPD Programmer | 4 – 10 VCD |
| M-Series II | 4 – 6 VDC |
| MicroM Series | 4 -10 VDC |
| MicroM Series w/display | 10 Minimum 20 – 80 Normal |

HONEYWELL CONTROLS

| | |
|----------------------|--------------------|
| RA890 Series | 2 – 6 UA DC |
| R4795 Series | 2 – 6 UA DC |
| R7795 Series | 2 – 6 UA DC |
| R4140 Series | 2 – 6 UA DC |
| R4150 Series | 2 – 6 UA DC |
| BC7000 Series | 2 – 6 UA DC |
| RM7890 Series | 1 ¼ - 5 VDC |
| RM7895 Series | 1 ¼ - 5 VDC |
| RM7840 Series | 1 ¼ - 5 VDC |
| RM7800 Series | 1 ¼ - 5 VDC |

**Use these in good health.
Eddy**

Emerson Boiler, Inc.

6081 N 57th Dr.

Glendale, AZ 85301

623-847-4788 Phone 623-847-2386 Fax

Web page www.boilersmadesimple.com or www.emersonboiler.com

E-mail EBBOILERMIKE@AOL.COM